


## Section 13



**Modular junction box**

## Section n °13

# Modular junction box

MODULAR JUNCTION BOX

13.1

CABLE JUNCTION BOX

13.18



# Section n°13 - Modular junction box

## MODULAR JUNCTION BOX



### 13.1 ATO Fuses Modules

Code	Type	A	Notes
354-501	single	60	2 ATO FUSES
354-502	double	120	4 ATO fuses
354-503	double	120	7 ATO fuses



### 13.2 Contacts for ATO Fuseholder

Code	Industrial Code	Wire Size Range (mm2)	Extraction Tool	Hand Tool
3607	913-071	1,00 - 2,00	25030	3991
3608	913-072	2,50 - 4,00	25030	3987



### 13.3 Frame for Modular Fuse Holder

Jumper bar for 7

Code
913-077



### 13.4 MINI Fuses Modules

Code	Type	A	Notes
354-543	single	60	6 MINI fuses
354-544	single	60	8 MINI Fuses



### 13.5 Contact for MINI Fuseholders

Code	Industrial Code	Wire Size Range (mm2)	Raw Material	Extraction Tool	Hand Tool
927779/3	927779/3	0,50 - 1,00	Bz Ph Sn	88040	3991
927781/3	927773/3	1,00 - 2,50	Bz Ph Sn	88040	3987



### 13.6 MAXI Fuses Modules


Code	Type	A	Notes
354-549	single	80	2 MAXI fuses
354-505	double	160	4 MAXI fuses



### 13.7 Contacts for MAXI Fuseholder

Code	Industrial Code	Wire Size Range (mm2)	Hand Tool
3602	913-064	1,50 - 2,50	3987
3606	913-068	2,50 - 6,00	3987

## Section n°13 - Modular junction box



### 13.8 Micro Relay Module

Code	Type	Notes
354-507	double	3 relays MICRO



### 13.9 Contact for Micro Relay Modules

Code	Industrial Code	Type	Wire Size Range (mm <sup>2</sup> )	Extraction Tool	Hand Tool
3603	913-043	medium contact	0,50 - 1,50	90028	3991
3601	913-055	medium contact	2,50 - 4,00	90028	3987
3605	913-067	little contact	0,50 - 1,50	90028	3991
3604	913-066	little contact	1,00 - 2,50	90028	3987



### 13.10 ISO Relay & Flasher Modules

Code	Type	Notes
354-506	single	1 MINI relay
354-536	double	2 relays MINI



### 13.11 Contact for Mini Relay Modules

Code	Industrial Code	Type	Wire Size Range (mm <sup>2</sup> )	Extraction Tool	Hand Tool
3603	913-043	medium contact	0,50 - 1,50	90028	3991
3601	913-055	medium contact	2,50 - 4,00	90028	3987



### 13.12 Power Relay Module

Code	Type	Notes
354-535	single	1 power relay



### 13.13 Contact for Power Relays

Code	Industrial Code	Type	Wire Size Range (mm <sup>2</sup> )	Raw Material	Extraction Tool	Hand Tool
3603	913-043	medium contact	0,50 - 1,50	-	90028	3991
3601	913-055	medium contact	2,50 - 4,00	-	90028	3987
182490/2	280756/2	big terminal	4,00 - 6,00	tin-plated brass	88074	3987



### 13.14 Stud Assembly Module 1 pin


Code	Screw Hole
354-539	M8
354-537	M6
354-538	M6

## Section n°13 - Modular junction box



### 13.15 Power Block accessories: empty module

Code
354-520



### 13.16 Power BLOCK accessories: module locking insert

Code
354-523



### 13.17 Power Block accessories: brackets

Code	Height	Notes
354-518	76,2	low attack
354-519	25,4	high attack
354-540	63,5	lateral attack

## Section n°13 - Modular junction box

### CABLE JUNCTION BOX



#### 13.18 Cable Junction Box 4 Fittings

Code
192052



#### 13.19 Cable Junction Box 12 Fittings

Code
192082